



### Connecting the Whip Lights to the Accessory Power Supply

- Plug one male connector from the Accessory Power Supply into the nearest female connector from the Whip Light Assembly.
- Plug the male connector from the Extension Harness into the other female connector from the Whip Light Assembly.
- Use the included zip ties to secure the wires to the chassis in the locations shown. **Note:** Ensure the wires are kept away from any moving parts and heated surfaces.
- Plug the red male connector from the LED Power Harness from the receiver box into the red female connector from the Accessory Power Supply.

The accessory power supply and LED whip lights will turn on when the electronic speed control is turned on. Always disconnect the battery when not in use.

If you have questions or need technical assistance, call Traxxas at  
**1-888-TRAXXAS**  
(1-888-872-9927) (U.S. residents only)