






Extended Outer Half Shaft Installation Instructions

Covers Part #8995, 8995A, 8995G, 8995R, 8995T, 8995X



Note: To install the extended outer half shafts, follow the steps in reverse order. Ensure the e-clip is pressed straight onto the end of the 3mm cross pin.



TRAXXAS.COM

Traxxas, 6250 Traxxas Way, McKinney, TX 75070, Phone: 972-549-3000, Fax: 972-549-3011, e-mail: support@Traxxas.com

KC2897-R02 Rev 210923